

Care Instructions

USE AND CARE

To care for AFRA FURNITURE products and maintain the characteristics of the materials overtime, it's necessary to follow some simple guidelines.

WOOD CARE

- Clean frequently using a soft, damp, clean cloth.
- Always dry after cleaning with a soft cloth.
- Remove liquid spills immediately to avoid absorption.
- Avoid prolonged exposure to direct sunlight, high humidity, extreme heat or cold, and moisture.

PLASTIC

- Clean with soft damp cloth and warm water.
- For persistent stains, liquid soap diluted in water can be used.
- Avoid detergents with acetone, trichloroethylene, ammonia and ethyl alcohol. They make shiny surfaces opaque.
- Avoid using materials or abrasive substances such as rough sponges, which can scratch plastic surfaces.
- Avoid prolonged exposure to direct sunlight, high humidity, extreme heat or cold, and moisture.

METAL

- Clean with soft damp cloth and warm water.
- For persistent stains, liquid soap diluted in water can be used.
- Always dry after cleaning with soft cloth or leather cloth.
- Do not use cleaning products for kitchenware or heavy-duty detergents.
- Avoid using materials which can scratch metallic surfaces.
- Avoid prolonged exposure to direct sunlight, high humidity, extreme heat or cold, and moisture.

For proper maintenance, the seating should be examined every 2 to 3 months for loose screws and seat pads, missing glides, broken casters, cracked welds, or any discrepancies and to be fixed and addressed immediately. Products should be handled with care, especially during cleaning, to avoid dropping and fracturing the furniture.